

SPK SERIES BACKGROUND SUPPORT KIT

INSTRUCTION MANUAL

A. Parts list

KIT MODEL	SPK-1	SPK-2	SPK-3
Background support, light stand L-2500H (A)	2 PCS	2 PCS	2 PCS
Background holder, hook for reeling set CBH-5 (B)	1 SET	2 SETS	3 SETS
Reeling set, B-REEL (C+D+E+F)	1 SET	2 SETS	3 SETS
Background paper (1.38M x 11M) (Selected by customers)	1 ROLL	2 ROLLS	3 ROLLS

B. Procedures of setting up the Background Support Kit

Pic.1 Assemble 1 set of B onto A accordingly and twist the knob tightly. (The small picture is the partially enlarged picture.)

Pic.2 Insert C into the background paper roll. Screw the knob according to the direction indicated by the arrow until C is fixed firmly.

Pic.3 Insert the other end of the background paper to D as instructed in Pic.2.

Pic.4 Fix C and D onto the indent of B after insertion of background paper.

Pic.5 Get 1 piece of E through the gear in D and F respectively. Then, close the joint of E. (The small picture is the partially enlarged picture.)

Pic.6 Pull E up and down to unfold and put away the background paper respectively.

Pic.7 To tailor individual needs, customers can assemble 1 or 2 sets of CBH-5, reeling set and 1 or 2 rolls of background paper as instructed by the above pictures.

